

ROTARY SWITCH SETTINGS

WIRING TYPES

- 0 C2 WIRING
- 1 B2 WIRING
- 2 D1 WIRING
- 3 E2 WIRING
- 4 T WIRING
- 5 TS WIRING


PROGRAM SETTINGS

- 6 MID-STOP TIMER TO CLOSE
- 8 WARNING LIGHT TIMER
- 9 SBC SINGLE BUTTON CONTROL
- B TIME TO CLOSE
- C MID-STOP
- D RUN-TIMER

CONNECTION FOR A RADIO RECEIVER MODULE. (CONSULT FACTORY)

TBS GND

NOTE:-
FOR ROTARY SWITCH SETTINGS AND PROGRAMMING PROCEDURES, REFER TO INSTRUCTION MANUAL



WARNING

① - USE 18AWG OR HIGHER FOR WIRING ALL EXTERNAL CONNECTIONS

② - MOTORISED DOORS CAN CAUSE SERIOUS INJURIES OR DEATH. MANARAS STRONGLY RECOMMENDS THE USE OF ENTRAPMENT PROTECTION SYSTEMS, ESPECIALLY IN THE OF CASE MOMENTARY CONTACT TO CLOSE AS IN B2 WIRING

THE INFORMATION CONTAINED HEREIN IS PROPRIETARY TO MANARAS-OPERA AND SHALL NOT BE REPRODUCED OR DISCLOSED OR USED FOR ANY DESIGN OR MANUFACTURE EXCEPT WHEN USER POSSESSES DIRECT WRITING AUTHORIZATION FROM MANARAS-OPERA

TITLE: **WIRING DIAGRAM, 120/208/240VAC, 1- PHASE**

DRAWN BY: BP DATE: 07.APR.2010 CAD FILE: EDWG1107006601 REV: D DATE: 02.NOV.2012

MANARAS-OPERA
436 ONEIDA DRIVE
POINTE-CLAIRE, QC H9R 1A8
TEL: 1-800-361-2260
FAX: 1-888-626-0606

KEY-SWITCH

RADIO RECEIVER

ON BOARD JUMPER SETTINGS

DISCONNECT SWITCH	PRESENT	NOT PRESENT
JP3	1,2	2,3

JP2 FOR 120VAC/240VAC

JP2	FOR 120VAC/240VAC
JP2	1,2

MONITORED PHOTOCELL

NOTE: FUNCTIONAL ONLY WITH M7-XX SOFTWARE NOT FUNCTIONAL WITH E7-XX SOFTWARE